

# HELLOLIGHTS.COM

<http://www.hellolights.com> 877-995-2677 [customer@hellolights.com](mailto:customer@hellolights.com)

**WARNING: Do NOT plug anything in until the ballast has been fully wired**

## Advance M137/M152 Wiring Instructions

1. Connect the **LAMP** wire from the ballast to the **BLACK** wire on the mogul socket with the **X-1-LAMP** wire on the igniter. Connect all three wires together.
2. Connect the **WHITE** wire on the mogul socket to the **COM** wire on the ballast and the **X2-COM** wire on the igniter. Connect all three wires together.
3. Connect the **X3** wire on the ballast to the **X3** wire on the igniter.
4. Connect one of the **CAP** wires on the ballast to either wire on the capacitor.
5. Connect the remaining **CAP** wire on the ballast to the remaining wire on the capacitor.
6. Connect the **120V** wire on the ballast to the **BLACK** wire on the power cord.
7. Connect the remaining **COM** wire on the ballast to the **WHITE** wire on the power cord.
8. The green wire on the power cord is the ground wire and should be connected to something metal/grounded.

